

ASSEMBLY INSTRUCTIONS

ITEM DESCRIPTION:

ITEM NO.: DPI14	NAME: Jordan Pendent
MATERIAL TYPE: Glass	FINISH: Frosted
SOCKET TYPE: E26	SOCKET QTY: 1
BULB WATTAGE: 40W BULB /10W SBCFL /9W SBLED	
VOLTAGE: 110-120V	ITEM NET WEIGHT: 9.2 Lbs

PARTS INCLUDED:

Mounting Plate	Qty: 1 PC
Canopy	Qty: 1 PC
Loop	Qty: 1 PC
Chain w/Link	Qty: 1 PC

HARDWARE INCLUDED:

Mounting Screws	Qty: 2 Pcs	
Plastic Wire Connector	Qty: 2 Pcs	
Green Ground Screw	Qty: 1 Pc	
Canopy Screw	Qty: 3 Pcs	
Hexanguler Screw	Qty: 1 Pc	

TO INSTALL YOU WILL NEED:

- 2 people recommended
- Phillips Screwdriver

These instructions are provided for safety. It is very important that they are read carefully and completely before beginning installation.

We strongly suggest that all hard-wired fixtures must be installed by a professional electrician.



PRE-ASSEMBLY:

Gently hook the suspended chain from the bottom with the METAL RING marked as "hanging chain" one by one & secure it by tightening the screw, apply same procedure to all remaining suspended chains. Now hold the rods coming out from socket & hook it with the METAL RING marked as "socket hook" repeat the same for all remaining rods.

TO ASSEMBLE:

1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
 2. Carefully unpack all fixture parts and hardware and lay them out on a clear workspace.
 3. Gently pull wiring down from ceiling junction box and allow it to hang.
 4. Remove the mounting plate from the canopy by loosening the canopy screws with a screwdriver.
 5. Carefully inspect the pendant's fixture wire. It is a round supply cord with insulating cover. Inside the insulation cover there are three conductor wire as follows:
Neutral fixture wire: White
Hot fixture wire: Black
Ground wire: Green
 6. Carefully strip the outer insulation cover taking care that the insulation of the inner conductors is not damaged. Strip approximately 3" of the outer insulation cover to expose the three conductor wires. Strip ¾" of the insulation off the three conductor wire.
 7. Attach the Ground wire from the pendant to the Ground junction box wire (usually green or bare wire). Fasten each together with a wire nut and wrap the connection with electrical tape.
 8. Attach the neutral fixture wire from the pendant to the neutral junction box wire (usually white). Fasten each together with a wire nut and wrap the connection with electrical tape.
 9. Attach the hot fixture wire from the pendant to the hot junction box wire (usually black). Fasten each together with a wire nut and wrap the connection with electrical tape.
- DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.** Always make sure that no wire strands are outside of the wire nut connectors.
10. Gently tuck the wire connections neatly into the ceiling junction box.
 11. Align holes in mounting plate with holes in junction box and attach with two mounting bolts. Secure bolts with a Phillips head screwdriver.
 12. Push canopy up over the mounting plate until it is flush with the ceiling.
 13. Push collar through hole in canopy and thread onto nipple on the mounting plate. Secure by turning collar clockwise until canopy is flush with the ceiling.
 13. Insert **(1) TYPE A 40W BULB / 10W SBCFL / 9 W SBLED** (not included) into the socket. **DO NOT EXCEED SPECIFIED WATTAGE.**
 14. Restore power to junction box and test fixture.

CARE INSTRUCTIONS:

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.

For customer service questions call 1-800-338-2150

A R T E R I O R S