

ASSEMBLY INSTRUCTIONS

ITEM DESCRIPTION:


ITEM NO.: 5771

NAME: Samara Entry Table

MATERIAL TYPE: Wood

FINISH: Ebony

ITEM NET WEIGHT: 79.5LBS



PARTS INCLUDED:

Table Top (A)	Qty: 1 Pc
Table Base (B)	Qty: 1 Pc
Washer (C)	Qty: 8 Pcs
Allen Bolt (D)	Qty: 8 Pcs
Allen Wrench (E)	Qty: 1 Pc
Glider (F)	Qty: 6 Pcs



TO ASSEMBLE:

- Step 1: Put a soft padding on the floor in a desired location of the room to protect the solid top. Lay the solid top on the padding with the bottom facing up. On another soft padding, put the base.
- Step 2. Place the base on the provision hole of the solid top.
- Step 3. Place the Allen bolt and washer on the provision hole. Make sure to position the Allen bolt and washer as pictured.
- Step 4. Using the Allen wrench, tighten the Allen bolt firmly but do not over tighten. Assembly is complete

- Do not throw away packaging materials until assembly is complete
- Assemble this item on a soft surface, such as cardboard or carpet, to protect finish.
- Proper assembly of this item requires two people

CARE INSTRUCTIONS:

Hardware may loosen overtime. Periodically check that all connections are tight. Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.

For customer service questions call 1-800-338-2150

ARTERIOS