

ASSEMBLY INSTRUCTIONS

ITEM DESCRIPTION:


ITEM NO.: FDS06

NAME: Anwar Dining Table

MATERIAL TYPE: Mahogany Wood

FINISH: Ebony

ITEM NET WEIGHT: 176 Lbs



PARTS INCLUDED:

A) Top	Qty: 1 Pc
B) Legs	Qty: 4 Pcs
C) Hanger Bolt	Qty: 8 Pcs
D) Lock Washer	Qty: 8 Pcs
E) Ring Washer	Qty: 8 Pcs
F) Allen Key	Qty: 1 Pc

TO ASSEMBLE:

1. This Item has two feet which need to be attached using the hardware and tools provided.
2. The feet have been marked A and B. The corresponding locations for these feet are also marked A and B on the bottom of the Frame. Match the direction of the letters on the frame and feet.
3. Place screw through base into rod and tighten with Allen wrench.
4. While fixing the feet do not tighten the Allen screws completely right away. Leave the screws little loose and move the feet to ensure that they settle correctly in the slot for the frame. Gradually tighten both feet ensuring that they are correctly mounted.
5. Stand the table upright to check that it stands vertical. If required press down gently to achieve proper alignment. You may have to loosen screws on feet to ensure proper fitting if the frame does not stand upright.
6. Tighten the screws completely to finish the assembly.

CARE INSTRUCTIONS:

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners. Hardware may loosen over time, periodically check that all connections are tight,



For customer service questions call 1-800-338-2150

ARTERIOS