

ASSEMBLY INSTRUCTIONS


ITEM DESCRIPTION:

ITEM NO: FDS19 NAME: FIGUEROA OUTDOOR
ENTRY TABLE

MATERIAL TYPE:TOP by Fibercement / Leg by Fibercement


FINISH: WHITE

ITEM NET WEIGHT :112.75 lbs Top / 85.80 lbs Base




PARTS INCLUDED:

1	TOP	A		QTY: 1 Pc
2	BASE	B		QTY: 1 Pc
3	Bolt M8x30C			QTY: 4Pcs
4	Washer M6 D			QTY: 4Pcs
5	Allen Key E			QTY: 1 Pc
6	Rubber F		30xH5mm	QTY: 4 Pcs



TO ASSEMBLE

- 1.Put the base on a rug or similar to help product surface from scratching and put the table top (A) on the base (B).
2. Attach the table top (A) to the base (B) by flat washers (C) , bolt (D) and tighten with Allen Key (E).
3. Checking all bolts and make sure they are even and tighten.



CARE INSTRUCTIONS:

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.