

ASSEMBLY INSTRUCTIONS

ITEM DESCRIPTION:

ITEM NO.: DMI21	NAME: Inaya Chandelier
MATERIAL TYPE: Brass	FINISH: Vintage Brass
SOCKET TYPE: E12	SOCKET QTY: 6
BULB WATTAGE: 25W BULB / 7W SBCFL / 5 W SBLED	
VOLTAGE: 110-120 V	ITEM NET WEIGHT: 27.23 LBS

PARTS INCLUDED:

Mounting Plate	Qty 1 PCS
Canopy	Qty 1 PCS
Chain	Qty 1 PCS

HARDWARE INCLUDED:

Mounting Screws	Qty: 2 Pcs	
Plastic Wire Connector	Qty: 2 Pcs	
Green Ground Screw	Qty: 1 Pcs	

TO INSTALL YOU WILL NEED:

- 2 people recommended
- Phillips Screwdriver

These instructions are provided for safety. It is very important that they are read carefully and completely before beginning installation.

We strongly suggest that all hard-wired fixtures must be installed by a professional electrician.



PRE-ASSEMBLY:

Gently hook the suspended chain from the bottom with the METAL RING marked as "hanging chain" one by one & secure it by tightening the screw, apply same procedure to all remaining suspended chains. Now hold the rods coming out from socket & hook it with the METAL RING marked as "socket hook" repeat the same for all remaining rods.

TO ASSEMBLE:

1. Gently pull wiring down from ceiling junction box and allow it to hang.
2. Remove the mounting plate from the canopy by loosening the canopy screws with a screwdriver.
3. Determine the Pipe length desired and if necessary, remove extra Pipes from assembly. The electric supply wire that is go through the pipe should be cut off 12 inches longer than the pipe. Cut the braided copper ground wire the same length. Split the supply wire down the center by a length of 3 inches and strip $\frac{3}{4}$ inch of insulation off the end of each wire. If you look very closely, you will notice that the plastic insulation of one of the two split wires has a rib on the outside edge. This ribbed wire is the "neutral" wire and the other is the "hot" wire; you will need to remember the difference later on when you connect these to the house wires in the electrical outlet box.
4. Insert the two stripped wires and the braided copper ground wire through the nipple assembly, locknut, mounting plate and mounting strip. Using the wire nuts, attach the ribbed wire to the white "neutral" house wire and the un-ribbed wire to the black "hot" house wire. Secure the wire nuts with black electrical tape. Connect the braided copper ground wire to the green ground screw marked "GRD" on the mounting strip. It is imperative that the outlet box in your home be properly grounded.
5. **DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.** Always make sure that no wire strands are outside of the wire nut connectors.
6. Gently push the wiring back into the outlet box. Screw the nipple assembly, locknut and canopy plate into the mounting strip and turn until the canopy is snug against the ceiling. Do not support the fixture from the electrical cord.
7. Insert **(6) TYPE A 25W BULB / 7W SBCFL / 5 W SBLED** (not included) into the socket. **DO NOT EXCEED SPECIFIED WATTAGE.**
8. Restore power to junction box and test fixture.

CARE INSTRUCTIONS:

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.