

# ASSEMBLY INSTRUCTIONS

## ITEM DESCRIPTION:

ITEM NO.: DMI26 NAME: Leonardo Chandelier

MATERIAL TYPE: Iron FINISH: Antique Brass

SOCKET TYPE: E12 Type B SOCKET QTY: 04

BULB WATTAGE: 40W BULB/10W SBCFL/9 W SBL

VOLTAGE: 125 V ITEM NET WEIGHT: 33.3LB



Spider & Decorative pipe



Socket Clustre

## PARTS INCLUDED:

Mounting Plate Qty: 1

Canopy Qty: 1

Pipes (1)3", (1)6", (2)12 Qty: 4

Socket Clustre Qty: 1

Spider & Decorative p Qty: 1

Dome Nut Qty: 3 + 1 Extra

## HARDWARE INCLUDED:

Mounting Screws 2 Allen Wrench 1

Plastic Wire Connect 2

Green Ground Screw 1

## TO INSTALL YOU WILL NEED:

- 2 people recommended
- Phillips Screwdriver

These instructions are provided for safety. It is very important that they are read carefully and completely before beginning installation.

We strongly suggest that all hard-wired fixtures must be installed by a professional electrician.



## TO ASSEMBLE:

1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
2. Carefully unpack all fixture parts and hardware and lay them out on a clear workspace.
3. Align the metal decorative spider with the large drum, matching the green dot to the green dot for easy positioning. Then fix the spider to the drum using the 3 dome nuts.
4. Insert and pull the wire through the center nipple of the spider at the top of the drum and decorative pipe. Then Screw the socket cluster onto the nipple by rotating it clockwise.
5. Included are (1) 3", (1) 6" pipe and (2) 12" pipes. Determine which of these you will need to reach your desired length. At least (1) 3" pipe must be used. Pass the attached electric cable through the desired amount of pipes, keeping the threaded part of the pipes toward the ceiling.
6. Screw each pipe to each other starting with the one closest to the Main Body and moving upwards to the canopy.
7. There is an Allen screw with each pipe and which should be tightened with the help of Allen wrench included with the hardware once pipes are assembled with each other as per desired height.
8. Gently pull wiring down from ceiling junction box and allow it to hang.
9. Remove mounting plate from the canopy by unscrewing the collar.
10. Carefully inspect the pendant's fixture wire. It is a round supply cord with insulating cover. Inside the insulation cover there are three conductor wire as follows:

Neutral fixture wire: White  
Hot fixture wire: Black  
Ground wire: Green

11. Carefully strip the outer insulation cover taking care that the insulation of the inner conductors is not damaged. Strip approximately 3" of the outer insulation cover to expose the three conductor wires. Strip 3/4" of the insulation off the three conductor wire.
12. Attach the Ground wire from the pendant to the Ground junction box wire (usually green or bare wire). Fasten each together with a wire nut and wrap the connection with electrical tape.
13. Attach the neutral fixture wire from the pendant to the neutral junction box wire (usually white). Fasten each together with a wire nut and wrap the connection with electrical tape.
14. Attach the hot fixture wire from the pendant to the hot junction box wire (usually black). Fasten each together with a wire nut and wrap the connection with electrical tape. **DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.**
15. Gently tuck the wire connections neatly into the ceiling junction box.
16. Align holes in mounting plate with holes in junction box and attach with two mounting bolts. Secure bolts with a Phillips head screwdriver.
17. Push canopy up over the mounting plate until it is flush with the ceiling.
18. Push collar through hole in canopy and thread onto nipple on the mounting plate. Secure by turning collar clockwise until canopy is flush with the ceiling.
19. Insert the three swift links (attached to the small drum) into the welded rings inside the large drum and tighten them securely.
20. Insert **(4) TYPE B 40W BULB / 10W SBCFL / 9 W SBL** (not included) into the socket. **DO NOT EXCEED SPECIFIED WATTAGE.**
21. Carefully insert the glass mouth into the cap and keep it balanced. While tightening the side screws, ensure that excessive pressure is not applied on the glass to prevent breakage. Repeat this process for all the arms.
22. Restore power to junction box and test fixture.

## CARE INSTRUCTIONS:

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.